



## TV FIELD STRENGTH METER


**APM 742** 


**SERVICE MANUAL** 


## **BLOCK DIAGRAM** Af . ATTENUATOR AMPLIFIER SELECTOR 20...90 48,4 YOLUME ATTENUATOR SMITCH 80...130 ea,v 🕞 ATTENUATOR IF SWITCH SWITCH AUDIO 108.00 STRINESIZER UNIT IF AMPLIFIER LOGIC → YOLT, CIRCUIT FREQUENCYMETER O CONT. I TELETEXT V10E0 AMPLIFIER DECODER FUNCTION SELECTOR SAWIOOTH GENERATOR INPUT EHT TO SATELLITE 1F TY 38.9 RECEIVER EP 815 YERTICAL & HORIZONTAL DEFLECTION 85 33 20 AGC M SYNC POWER SUPPLY ∿ 220 V STHE JUB 50 Hz BATTERY CHARGER DISPLAT . ONLY FOR FM VERSION TY YOL. EST DC POWER IF/5,5 IF AMPLIFIER


















ट्








8/






































## CURRENT LIMITER

